



FACEPLATE INSTALLATION

CFP, CFPL & CFPE Module Installation




Note: Logo orientation is not an indicator of faceplate mounting direction.

CFPSL & CFPHSL Module Installation



MODULE REMOVAL



Cover Installation (CFPE, CFPL, CFPSL, CFPHSL ONLY)

